

General information

For information on safety instructions, cleaning, technical information or connecting to a switchboard, please refer to the 'General information' section in the full user guide at bt.com/producthelp

Guarantee

Your BT3660 is guaranteed for 12 months from the date of purchase. Subject to the terms listed below, the guarantee will provide for the repair of, or at BT's or its agent's discretion, the option to replace the BT3660 or any component thereof, (other than batteries), which is identified as faulty or below standard, or as a result of inferior workmanship or materials. Products over 28 days old from the date of purchase may be replaced with a refurbished or repaired product.

Guarantee conditions

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is provided.
- The equipment is returned to BT or its agent as instructed.
- This guarantee doesn't cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.
- This guarantee does not affect your statutory rights.

How to recycle your equipment

The symbol shown here and on the product means that the product is classed as electrical or electronic equipment, so DO NOT put it in your normal rubbish bin.

It's all part of the Waste Electrical and Electronic Equipment (WEEE) Directive to recycle products in the best way – to be kinder to the planet, get rid of dangerous things more safely and bury less rubbish in the ground. You should contact your retailer or supplier for advice on how to dispose of this product in an environmentally friendly way.

Radio Equipment Directive Declaration of Conformity

Hereby, British Telecommunications plc declares that the radio equipment type BT3660 Telephone (093665, 093666, 093667) is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: bt.com/bt3660

EU Frequency band restriction

This device may be used in each member state.

Radio transmission information

Frequency range

1881.792 – 1897.344MHz

Max power

21.0dBm or 125.89mW

Operating temperature

0°C to 40°C.



Offices worldwide

The services we've described in this publication may not always be available and we may change them. Nothing we've written here is contractual. When we supply services and equipment, our terms and conditions apply.

© British Telecommunications plc 2018
We're registered in England at 81 Newgate Street, London EC1A 7AJ (company number 1800000).

Designed and produced by The Art & Design Partnership Ltd.

BT3660 (04/18) Issue 1



BT3660 with nuisance call blocking and answer machine User Guide

Digital Cordless Phone with Answer Machine




You'll need Caller Display



To get the most from your nuisance call blocker phone and for all the features to work, you'll need to subscribe to a Caller Display service from your network provider. Charges may apply.

Check the box contents

- If you bought more than one handset you'll also get:**
- Extra handset
 - Charger with mains power adaptor (item code 094096)
 - Two rechargeable batteries, AAA NiMH 300mAh (already installed in the handset)
- Important – please read first**
- Only use the line cord, power supply and rechargeable batteries that come with your phone.
 - Make sure the power supply is connected to a socket that you know works.
 - Connect your phone to the power supply and let the batteries charge for 16 hours before connecting your phone to the phone socket.
 - The base should always be plugged in to the mains power supply.
- Your Answer Machine**
- Make sure the phone is set to **ANSWER+REC** before any voicemail service does. The default setting is five rings.



Getting to know your phone



Set-up


1. Plug in

1. Plug the mains power adaptor into the base, with the cable clipped in the groove provided.
2. Plug the other end of the power adaptor into the wall power socket and switch on. The phone line cord is pre-installed but don't plug the other end into the wall socket yet.



Important

- Don't connect the phone line to a phone socket until the handset is fully charged.
- The base station should be plugged into the power socket all the time.





Using the phone




You'll need Caller Display

To get the most from your nuisance call blocker phone and for all the features to work, you'll need to subscribe to a Caller Display service from your network provider. Charges may apply.


Make and end a call

1. Press green , enter phone number using keypad.
2. Press red  to end the call.

Answer a call






1. Press green  to answer the call.

Mute

1. Press  during a call. Press  to return to your caller.

View or dial a number in Calls list†

The Calls list stores details of the last 20 incoming calls.



1. Press  to open the calls list and scroll to an entry.
2. Press  to dial the number. Or to view call details, press , 'view' will be displayed, press  again to see date and time, and then press  again to see callers number.

Where to put your phone

- Place the base within 2 metres of a mains power socket and 1.8 metres of a phone socket so the cables will reach.
- Make sure it's at least a metre away from other electrical appliances to avoid interference.
- Don't place the phone or base in a bathroom or other humid area.
- The product works by sending radio signals between the handset and base. The strength of the signal depends on where you position the base. Putting it as high as possible can help give you the best signal.

2. Charge


1. Slide off the battery cover from the back of the handset and insert the two batteries supplied. Note the '+' and '-' markings inside the battery compartment. Then slide the battery cover back into place.
2. The handset will then check for a link with the base station.
3. When it's found it, place the handset on the base and let it charge for 16 hours.
4. After 16 hours, plug the phone line cord into the phone wall socket.



Talk/Standby time

Under ideal conditions, the handset batteries should give up to 10 hours talk time or 100 hours standby on a single charge. (This doesn't mean you can unplug the base or leave the handset for this length of time without charge). Please note that new Ni-MH rechargeable batteries don't reach full capacity until they've been in normal use for several days.








Battery low warning

You will hear a warning beep every 2 minutes during a call and the  icon will flash. You must recharge the handset batteries before you can use the handset. If the charge completely runs out the handset will switch off. Place the handset on the base or charger to charge.


Set up for additional handsets (multipacks only)

1. Plug the mains power adaptor into the mains wall socket and switch on the power.
2. Activate the batteries as explained in point 1 in Charge above.
3. Place the handset on the charger to charge for 16 hours.

Using the menu



Press  to open the main menu, scroll through menu items using  or . When the menu you want is displayed, press . Press  or  to scroll through the sub menus and press  to select.

Use  to return to the previous menu level.









Use  to exit a menu and return to standby.

If no buttons are pressed for 30 seconds the handset will return to the idle screen.










Incoming speech/Handsfree volume

During a call, press  or  to increase or decrease the volume of your caller's voice.

Handset ringer volume

1. Press , scroll  to PERSONAL SET, press .
2. Display shows HANDSET TONE, press .
3. Display shows RING VOLUME, press .
4. Press  or  to adjust the volume, press  to save.

Handset ringtone


1. Press , scroll  to PERSONAL SET, press .
2. Display shows HANDSET TONE, press .
3. Press  to RING MELODY, press .
4. Press  or  to hear ringtones, press  to save.

3. Go!


Using your BT3660 Phone on a line with broadband?

To avoid problems with your broadband or noise on your phone line, you might need to plug your telephone line cord into the wall via a microfilter (not supplied).

If your main phone socket has a single socket, as shown, you'll need to use microfilters.



You don't need to use microfilters if your main phone socket has two separate sockets, like either of these:



Using the keypad

- When entering letters you may need to press the same button a few times until the letter you want is displayed, e.g. press **2**[®] once for A, twice for B, three times for C
- Enter a space, press **1**↵
- Enter a pause when pre-dialling or storing a number, press and hold **##**

Free Technical Help & Support

A full list of frequently asked questions and the complete user guide are available online. bt.com/bt3660

Phone doesn't work

- Have you activated the batteries correctly?
- Check that the mains power is correctly connected.

No dial tone or line cord error message displayed on screen

- Is the telephone cord plugged into the base and phone wall socket?
- Check that the mains power is correctly connected.
- Only use the telephone cord supplied with the phone.

Can't make or receive calls

- Check that the mains power is correctly connected.
- The batteries may need recharging.
- Has there been a power cut? If so, place the handset back on the base for ten seconds and try again. If it still doesn't work, disconnect the batteries and mains power for ten minutes, then reconnect and try again.

Handset doesn't ring

- The ringer volume may be switched off.
- Check that the mains power is correctly connected.

No display

- The batteries may be flat, dead or incorrectly inserted.
- Recharge or replace the batteries.

Customer Helpline

If you're still having problems, call us on **0800 145 6789*** or go to bt.com/bt3660

General sales enquiries

- BT Residential lines – call **150**. BT Business lines – call **152**.
- For non BT line customers, call **0800 800 150** (residential) or **0800 800 152** (business).

Billing enquiries

Please see the phone number shown on your BT bill.

* Calls made from within the UK mainland network and mobile networks are free. International call costs may vary.
† Requires a subscription to a Caller Display service from your network provider. Charges may apply.