

The Camera unit can be wall mounted using the wall mounting bracket supplied. For instructions, see your original BT Digital Video Baby Monitor 1000 User guide or view online at www.bt.com/producthelp

Removing the batteries
If you ever need to remove the batteries, unplug the power adaptor, then open the battery compartment cover and use the ribbon to gently pull them out.

2. Plug the power adaptor cable (item code 064785) into the socket marked **B** on the side of the Baby unit and plug the other end into the mains power and switch on.

General information

For information on important safety instructions, cleaning or further help, please refer to the full user guide at www.bt.com/producthelp

Guarantee

Your BT Digital Video Baby Monitor 1000 Additional Camera is guaranteed for a period of 12 months from the date of purchase.

Subject to the terms listed below, the guarantee will provide for the repair of, or at BT's or its agent's discretion the option to replace the BT Digital Video Baby Monitor 1000 Additional Camera, or any component thereof, which is identified as faulty or below standard, or as a result of inferior workmanship or materials. Products over 28 days old from the date of purchase may be replaced with a refurbished or repaired product.

The conditions of this guarantee are:

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is required.
- The equipment is returned to BT or its agent as instructed.

This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.

This guarantee does not affect your statutory rights.

For further information within and outside the 12 month guarantee, please refer to the full user guide at www.bt.com/producthelp

Product disposal instructions

The symbol shown here and on the product means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life.

The Waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increasing landfill.

Product disposal instructions for residential users

When you have no further use for it, please remove any batteries and dispose of them and the product as per your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.

R&TE Directive & Declaration of Conformity


This product is intended for use within the UK.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive (1999/5/EC).

For a copy of the Declaration of Conformity please refer to www.bt.com/producthelp



Warning
Do not mix old and new batteries. Only use the recommended type of 4 AA batteries. Using other types could permanently damage the unit.



1. Install 4 AA batteries (not supplied) into the battery compartment as shown observing the polarity markings inside. Then replace the battery compartment cover.
The operating time for using AA batteries is approximately 8 hours depending on light conditions and feature usage. If you want to monitor your baby for long periods we strongly recommend you connect the power adaptor to the Camera unit.
The Camera unit can be powered up using the power adaptor provided or using 4 AA batteries (not supplied). Even if the power adaptor is used, we recommend that you also install batteries to guarantee continual operation in the case of a power cut.

1 Setting up

Find out more

- New Frequently Asked Questions available at www.bt.com/producthelp
- If you need more detailed instructions, the full BT Digital Video Baby Monitor 1000 user guide is available to download from www.bt.com/producthelp
- If you cannot find the answer to your problem in the full online user guide, then please call the free Helpline on 0808 100 6554*. Our dedicated advisors are more likely to be able to help you than the retailer where you made your purchase.
- This document is also available in other formats, such as Large print, Braille and Audio CD. If you would like a copy, please call 0808 100 6554*.

BT is a sustainability leader

To find out how we're making our products greener visit

bt.com/betterworld/products

Offices worldwide

The services described in this publication are subject to availability and may be modified from time to time. Services and equipment are supplied subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of a contract.

© British Telecommunications plc 2011.
Registered Office: 81 Newgate Street, London EC1A 7AJ.
Registered in England No. 1800000.

Designed and produced by The Art & Design Partnership Ltd.
Printed in China / Issue 1 / ADP11-11



Additional Camera
For Digital Video Baby Monitor 1000



Bringing it all together

User Guide




Setting up is easy. Just follow the simple steps in this guide. If you need further assistance, please visit our website www.bt.com/producthelp to view our advanced user guide or call our helpdesk on 0808 100 6554*

* Calls made from within the UK mainland network are free. Mobile and International call costs may vary.



This quick start guide to get your new camera connected to your BT Digital Video Baby Monitor 1000




Check box contents


Please refer to your original BT Digital Video Baby Monitor 1000 User guide if you want to wall mount your Camera unit. This User guide can also be downloaded from www.bt.com/producthelp
Important: Only use the mains power adaptor supplied in this box or your product may not work.

Your Additional Camera

Front



Back



2 Pairing and testing

You will need to pair your new Camera unit to your BT Digital Video 1000 Parent unit before you can use it. You can pair a maximum of four Camera units to your Parent unit.

To pair the Camera unit to your Parent unit

1. Firstly, make sure the Camera and Parent units are turned on, by pressing and holding the power buttons on each unit.
2. Press on the Parent unit.
3. Press or to highlight **PAIR/UNPAIR CAM**, then press or .
4. Press or again to select **Pair new CAM**.
5. Press or to choose a Camera unit slot, then press .
6. When the display shows **Please press both and keys on CAM side until POWER indicator flashes Red and Green light**, press and hold the and buttons for 5 seconds on the Camera unit. The light on the of the Camera unit will flash red and green alternately.
7. When pairing has been successful, the screen will display the image from the newly paired Camera unit. The light on the of the Camera unit will turn red when it is powered by AA batteries or green when powered by the power adaptor.

If pairing fails, the screen will display **Pairing failed**. Try the pairing procedure again. If you pair a new Camera unit to an already occupied Camera unit slot it will unpair the current Camera unit. Only one Camera unit can be paired at a time.

Testing the units before use

It is important that you test the units before use and at regular times thereafter, especially if they have not been used for some time.

To test your units

1. Place the Parent and Camera units in the same room but make sure they are at least 2 metres apart.
2. Press and hold the on the Camera unit until the Power light on the button turns on.
3. Press and hold the on the Parent unit until the display shows **Waiting for linking** and the Link light flashes.
4. Press the on the Parent unit to view the image from the Camera unit.

If no connection can be established, the Parent unit will display **No link to CAM** for a few seconds, then **Waiting for linking...** The Link light will continue to flash.

Positioning and operating range

Positioning

We recommend you place the Camera unit between 1-2 metres away from your baby for best performance. Make sure the unit and cable is out of reach of your baby. Do not place the Parent and Camera units too close together as you will hear a high-pitched noise, this is normal. The units are designed to be located at a distance from one another, e.g. in separate rooms.

Operating range

The operating range is up to 300 metres outdoors and 50 metres indoors. The actual operating range may vary depending on the environmental conditions and other interferences such as walls, doors and other obstructions.

3 Go!

Switch the Camera unit on/off

1. Press and hold the button until the light on the button turns on.
2. To turn the Camera unit off, press and hold the button for 2 seconds. The light will turn off.

Adjust the Camera unit loudspeaker volume

You can adjust the loudspeaker volume from Level 1 to Level 5. The default setting is Level 3. If you adjust the loudspeaker volume it will also adjust the parent voice (Talk) playback volume.

When the maximum or minimum volume levels have been reached you will hear an error tone.

1. Press the or button on the Camera unit at any time to increase or decrease the loudspeaker volume.

Play lullabies from the Camera unit

The Camera unit has five lullabies that can be played to gently soothe your baby. The total lullaby playback time is about 15 minutes and it starts from where you stopped it last time.

To play lullabies

Press the button to play.

Press the button to skip to the next lullaby.

Press the button to stop playback.

Lullaby playback will be paused if the Talk feature is being used from the Parent unit, when finished lullaby playback will resume.

Night vision

To help you monitor your baby at night, the Camera unit automatically uses the light from its infrared LEDs when it is turned on in a dark room. However, it only transmits black and white images in this mode.

The LEDs on the Camera unit may glow red slightly in dark conditions, this is normal.

To unpair a Camera unit from the Parent unit

1. Firstly, make sure both units are turned on, then press on the Parent unit.
2. Press or to highlight **PAIR/UNPAIR CAM**, then press or .
3. Press or to select **Unpair CAM**, then press .
4. Press or to select the Camera unit you want to unpair, then press .
5. When the display shows, **To unpair CAM # from the system**, press key, press the button.
6. When the display shows, **Press key to confirm**, press .
7. When unpairing has been successful, the screen will display the image from the next paired Camera unit. If there is no paired Camera unit, the screen will display **NO CAM paired**.