


## What's in the box


### Whole Home Wi-Fi disc



### Ethernet cable



### Power adapter



## Safety instructions and care

Your Whole Home Wi-Fi from BT is manufactured to comply with European safety standards. Please read the following instructions carefully before installing and using it. Keep these instructions safe for future reference.

### Installation and location

- For indoor use only in the UK.
- Position all parts, including power adapters, away from heat and sun (eg away from radiators, window sills or other electrical equipment that can get hot).
- Keep area ventilated (eg don't put behind sofas or in cupboards) and don't block any vents with objects or thick carpets.
- Keep cables out of children's reach.
- Only use power adapters provided by BT for this specific device; contact the BT helpdesk if you need a replacement.
- Electronic devices hate liquids; don't place devices and power adapters in damp areas or near sources of water or splashes.
- Product may cause scratches or marks if placed on fragile surfaces (eg veneered wood or delicate fabrics); place on a mat if needed.
- Designed for use at room temperatures between 0 and 40°C.

### Care and maintenance

- Dust with a soft dry cloth; don't use water or solvent.
- Regularly check that objects don't cover any parts or any vents that could cause overheating.

### Warnings

- If your devices or power adapters appear damaged, stop using them immediately. Switch off your electrical socket if it's safe to do so and contact the BT helpdesk. See terms of the guarantee.
- Don't try to open your devices or power adapters. There are no serviceable parts and you risk an electrical shock.
- This device has been evaluated for and shown to be compliant with European Guidelines when installed and operated with a minimum distance of 20cm between the unit and your body.

### Disposing of your old electrical and electronic equipment

The Government has a legal requirement to minimise the unsorted waste disposal of electrical and electronic equipment and to maximise its separate collection and environmentally sound management. The symbol shown above and on a product, means you shouldn't throw it in your normal rubbish at the end of its working life.



This product may contain substances that could be harmful to people or the environment if it's not recycled correctly. Check with your retailer to find out how to recycle your old equipment, or if you've bought something from us that has the crossed out wheelee bin symbol on it and it's similar to the kit you don't need any more, you can send us your old kit and we'll get rid of it in an environmentally friendly way. Here's the address: WEEE Take Back Scheme, BT Returns, BT DF, Darlington Road, Northallerton DL6 7ZY

Website address: [bt.com/weee](http://bt.com/weee)

We're not responsible for the costs of returning items. If you don't wish to return kit to us, lots of electronics shops have their own 'take back' schemes where you can recycle very small electrical and electronic goods. If you're a household user, you can also take it to your local recycling centre – go to [recyclenow.com](http://recyclenow.com) to find the one nearest to you. Please dispose of this carefully and help to protect our planet.

## Other information

Whole Home Wi-Fi contains code that is covered by the GNU General Public License (GPL). In accordance with the GPL, BT has made the relevant code available for download at [bt.com/help/gplcode](http://bt.com/help/gplcode)

### Radio Equipment Directive Declaration of Conformity

Hereby, British Telecommunications plc declares that the radio equipment type Whole Home Wi-Fi (088269, 091073 & 092099) is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [bt.com/wholehomewifi](http://bt.com/wholehomewifi)

Restrictions						
Operations in the 5.15–5.35GHz band are restricted to indoor usage only.						
BE	BG	CZ	DK	DE	EE	IE
EL	ES	FR	HR	IT	CY	LV
LT	LU	HU	MT	NL	AT	PL
PT	RO	SI	SK	FI	SE	UK
NO	IS	LI	CH	TR		

### Radio transmission information

Frequency range (MHz)	Max power in the range
2401–2473	99.77mW (19.99dBm)
5170–5250	198.15mW (22.97dBm)

### Power consumption (per disc)

Disc status	Watt/s
In operation	7.09W
Network standby	4.27W
Off mode	0.07W

Elapsed time before going into 18 minutes standby mode

## Guarantee

Your Whole Home Wi-Fi is guaranteed for three years from when you bought it. This means we'll either repair it or replace all or part of the product if it isn't working properly. If you bought the product more than 28 days ago, we might replace it with a refurbished or repaired one.

Guarantee conditions:

- the guarantee only covers problems found in the 3-year guarantee period
- you'll need your receipt or other proof of purchase
- your product is returned to BT or one of our partners as instructed
- this guarantee doesn't cover any problems caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents
- this guarantee doesn't affect your statutory rights.

Available in other formats including braille, large print or audio CD. If you would like a copy, please call **0808 100 6116\***.



Works with all broadband providers

## Let's get started

### Whole Home Wi-Fi Add-on

Need some help?

Go to [bt.com/wholehomewifi](http://bt.com/wholehomewifi)

See frequently asked questions. It's the quickest and easiest way to get help.

Call us on **0808 100 6116\***

Monday to Friday 9am to 5.30pm,  
Saturday 9am to 2pm.

\* Calls to our helpdesk made from the UK mainland and mobile networks are free. International call costs vary.

© British Telecommunications plc 2019  
We're registered in England at 81 Newgate Street, London EC1A 7AJ, UK (company number 1800000).

All third-party trademark rights are acknowledged.

Apple and the Apple logo are trademarks of Apple Inc., registered in the US and other countries. App Store is a service mark of Apple Inc. Android, Google Play and the Google Play logo are trademarks of Google LLC.

WHW Add-on 4.1



# Let's set up your disc

**Important:** make sure you've already set up your Whole Home discs. Please **don't switch on** your new Add-on disc until the app says you can.

## 1 Move near your hub

You need your new disc and your mobile device with the Whole Home Wi-Fi app installed.

We'll tell you later when to move the disc to where you want it.

### Not got the app?



Go to the app store for your device and search for 'Whole Home'.

If you're using an iPad, you may need to select 'iPhone only' at the top of the app store screen.




Whole Home Wi-Fi app works with iOS 9 and above, and Android™ 5.0 and above.

## 2 Open the app and connect the new disc

Tap **Settings**, then **Add Another Disc**.

- a Plug one end of the Ethernet cable into your hub/router and the other end into the new Add-on disc.
- b Plug in the power adaptor and turn the disc on.

**Note:** Don't unplug your existing disc from the hub/router.




## 3 Sync the new disc

Follow the steps on the app to link your new disc to your existing Whole Home Wi-Fi network.

Your disc will start up and sync with your existing network. The disc's lights will flash for a short time while it checks for any updates.

**Note:** Wait for the light to stay solid blue for one minute.



## 4 Locate the new disc

You're now ready to unplug the Add-on disc and move it to your desired location.

Use the app to find a suitable place for your new disc. The app will then tell you when to turn the disc on and finish set-up.

### Wi-fi password




Your new disc uses the same wi-fi details as your existing discs. You can write these on the blank wireless card on the back of your new disc.

## Where's best?

Follow your app's location checker to find the best place for your disc(s). Make sure they aren't:

- covered or in a confined space – the vents on your discs should always be clear from anything that might block them
- on soft furnishings, carpets or delicate surfaces.

Here are some examples of how you might place the discs:



For extra coverage, you can buy more Whole Home Wi-Fi Add-on discs at [bt.com/shop](http://bt.com/shop)

### Compatibility with other discs

Only **Whole Home Wi-Fi Add-on** discs will work with your existing Whole Home Wi-Fi network. These discs are not compatible with **Premium** or **Mini** Whole Home Wi-Fi discs, or BT's Complete Wi-Fi service.

## What your disc lights mean

If your disc isn't showing a steady blue light, it might need a bit of help.

<p><b>Blue</b></p>	<p>The disc is connected and working okay If you can't get online, there might be a problem with your computer, tablet or mobile device</p>	<p><b>Slow flashing blue</b> (every two seconds)</p>	<p>The disc is in WPS mode Press the WPS button on the device you want to connect</p>
<p><b>Fast flashing blue</b> (every half second)</p>	<p>The disc is connecting to the Whole Home network Wait about 15 seconds</p>	<p><b>Purple</b></p>	<p>The disc is starting up Wait a minute for it to turn blue</p>
<p><b>Flashing purple</b></p>	<p>The disc is updating itself Don't turn it off while it's doing this. Updating takes a couple of minutes</p>	<p><b>Orange</b></p>	<p>The disc is okay but could be closer to others Try moving it nearer to one of your other discs</p>
<p><b>Red</b></p>	<p>There's a problem somewhere Check the Ethernet connection with your hub. If needed, restart the disc (switch off then on). If the light's still red, try moving it nearer to one of your other discs</p>		



### Need to reset a disc?

Use a pin or paper clip to press the **Factory Reset** button on the back of the disc for about one second.