

Your BT Freelance XD7500 is now ready for use.

3 Place handset on the charger to charge for 16 hours.

2 Activate batteries as shown above.

1 Into the mains wall socket and switch the power on.


045667) into the socket on the underside of the charger and plug the other end into the mains power adapter (item code

Set up your additional handsets (multipacks only)



16hrs
or your phone may not work.


① Important: Charge the handset batteries for 16 hours



- 1 Activate batteries by pulling the plastic tab away from the back of the handset.
- 2 Place handset on base to charge.
- 3 After 16 hours, plug the telephone line cord into the telephone wall socket.

- 1 Plug in telephone line cord but **don't** plug the telephone line cord into the wall socket yet.
- 2 Plug in mains power adapter (item code 040367) into the mains wall socket and switch on.
- 3 Place handset on base to charge.

- 1 Plug in telephone line cord into the wall socket and switch on.
- 2 Place handset on base to charge.
- 3 After 16 hours, plug the telephone line cord into the telephone wall socket.



2 Charge

General information

For information on safety instructions, cleaning, technical information or connecting to a switchboard, please refer to the 'General Information' section in the full user guide at www.bt.com/producthelp

Guarantee

Your BT Freelance XD7500 is guaranteed for a period of 12 months from the date of purchase.

Subject to the terms listed below, the guarantee will provide for the repair of, or at BT's or its agent's discretion the option to replace the BT Freelance XD7500, or any component thereof, (other than batteries), which is identified as faulty or below standard, or as a result of inferior workmanship or materials. Products over 28 days old from the date of purchase may be replaced with a refurbished or repaired product.

The conditions of this guarantee are:

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is required.
- The equipment is returned to BT or its agent as instructed.

This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.

This guarantee does not affect your statutory rights.

For further information within and outside the 12 month guarantee, please refer to the full user guide at www.bt.com/producthelp

Product disposal instructions



The symbol shown here and on the product means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life.

The Waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increasing landfill.

Product disposal instructions for residential users
When you have no further use for it, please remove any batteries and dispose of them and the product as per your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.

Product disposal instructions for business users
Business users should contact their suppliers and check the terms and conditions of the purchase contract and ensure that this product is not mixed with other commercial waste for disposal.

R&TE Directive & Declaration of Conformity

This product is intended for use within the UK for connection to the public telephone network and compatible switchboards.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive (1999/5/EC).

For a copy of the Declaration of Conformity please refer to www.bt.com/producthelp

In order to make our products more sustainable this user guide uses less paper than our previous guides.

BT is a sustainability leader

To find out how we're making our products greener visit bt.com/betterworld/products

Offices worldwide

The services described in this publication are subject to availability and may be modified from time to time. Services and equipment are supplied subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of a contract.


© British Telecommunications plc 2008.
Registered Office: 81 Newgate Street, London EC1A 7AJ.
Registered in England No. 1800000.

Designed and produced by The Art & Design Partnership Ltd.


Printed in China / Issue 1 / ADP07-08



Important: Only use the cables and rechargeable batteries supplied in this box, or this product may not work. Any replacement rechargeable batteries must be of the same type.



Contents for each additional handset (multipacks only)



Check box contents



Bringing it all together

BT Freelance XD7500 User Guide

- 1 Plug in
- 2 Charge
- 3 Go!




Setting up is easy. Just follow the simple steps in this guide.
If you need further assistance, please visit our website www.bt.com/producthelp to view our advanced user guide or call our helpdesk on 0800 218 2182*.


* Calls made from within the UK mainland network are free. Mobile and International call costs may vary.

Your phone

Handset



Base



3 Go!

Set time and date

Press **1** left soft key (the left-hand **1** button) to open main menu. Press **2** to scroll to **HS SETTINGS** and press **OK** soft key. **DATE & TIME** is displayed, press **OK** soft key. Press **2** to **SET TIME** and press **OK** soft key. Enter 2 digits for the hour and 2 for the minute using the 24hr format and press **OK** soft key. You will hear a confirmation tone. Press **2**, **SET DATE** is displayed. Press **OK**. Enter the day, month and year using the dd-mm-yy format and press **OK**. You will hear a confirmation tone.

Making calls

Press **1** then dial the phone number. Press **2** to end the call.

Answering calls

If you have subscribed to Caller Display, the caller's details will be displayed before you answer (see the full user guide online at www.bt.com/producthelp for details).

Lift the handset from the base or charger to answer incoming calls. If the handset is not on the base or charger, press **1**.

Handsfree

Press **1** during a call to switch the call to loudspeaker.

Secrecy (Mute)

Press the **C** soft key during a call to activate secrecy mode. Press the **C** soft key again to resume your call.

Redial

Press **2**. Press **1** or **2** to scroll through the list.

Press **1** to redial the number displayed.

Directory

Storing new directory entries

Press **1**. The first entry (or **LIST EMPTY**) is displayed.

Press the **1** left soft key, **ADD** is displayed. Press **OK**. **NAME** is displayed. Using the letters on the keypad, enter the name, then press **OK**. You may need to press the same button a few times until the letter you want is displayed. For example, press **2** once for **A**, or twice for **B**. **NUMBER** is displayed, enter the phone number for the entry and press **OK**.

Press **1** or **2** to select a ringtone to associate with the entry and press **OK** to confirm. Press **1** to return to standby.

Dialling a directory entry

Press **1**. Scroll **1** or **2** to the entry you want. Press **1** to dial.

Caller Display and the Calls list

1 You must subscribe to a Caller Display service for this feature to work. Your network provider may charge you for this service.

View and dial from the Calls list

Press **1**, then **1** or **2** to scroll through the last 40 incoming calls.

Press **1** or **2** to dial the number displayed.

Answering machine

Your answering machine is on and ready to record messages. The controls are shown in the base diagram to the bottom left and the features can also be accessed via the handset **Ans. Machine** menu.

Recording your own outgoing message

Press the **1** left soft key, display shows **Ans. Machine** and press **OK**.

Press **1** to scroll to **Ans. Settings** and press **OK**.

Press **1** to scroll to **Outgoing Message** and press **OK**.

Press **1** to **2** to select either **Ans & Rec** or **Answer Only** and press **OK**.

Press **1** to scroll to **Recording MSG** and press **OK** to record your message.


When prompted, speak your message into the handset. When finished press **OK**. Your message will be played back to you.

1 For detailed instructions on all the answering machine features see the full user guide online at www.bt.com/producthelp

Help

Most problems can be fixed with a few simple checks.

Problem	Solution
No dial tone	Only use the cables and batteries supplied.
Poor speech quality	Make sure the product is not located too close to other electrical appliances. This can also help improve the handset range from the base.
Battery icon not full/handset dead	Make sure you charge the batteries for 16 hours before use to ensure maximum battery performance.
Using broadband on the same phone line?	Make sure you plug the phone into the wall socket via an ADSL microfilter (not supplied), otherwise you may have problems with this product and your broadband service.



Find out more

- New Frequently Asked Questions available at www.bt.com/producthelp
- If you need more detailed instructions, a full user guide is available to download from www.bt.com/producthelp
- If you cannot find the answer to your problem in the full online user guide, then please email bt.helpdesk@vtecheurope.com
- Call the Helpline on **0800 218 2182***