

Your BT Diverse 7450 is now ready for use.

Press **OK**.
 Press **OK** to Enter Date and press **OK**. Enter the date, e.g. 09.04.2010 for 9 April 2010.
 was chosen, press **OK** or **Call** to select AM or PM and press **OK**.
 Press **OK** to Enter Time and press **OK**. Enter the time using the keypad as either the 24 or 12 hour format (previously selected) e.g. 17:30 or 05:30pm. If 12 hour
 Press **OK** to Date Format and press **OK**. Scroll **OK** or **Call** to choose DD/MM/YYYY or
 Press **OK** or **Call** to choose 24 Hour or 12 Hour and press **OK**.
 Date & Time is highlighted, press **OK**. Time Format is highlighted, press **OK**.
 Press the right soft key **OK** (Menu) and scroll **OK** to Settings, press the right
 soft key **OK** (OK).


Set time and date

Providing you have subscribed to your network's Caller Display service the date and time is set automatically when you receive your first call. To set the date and time manually follow the procedure below:

- 1 Remove the protective film from the handset screen and activate the batteries by pulling the plastic tab away from the back of the handset.
- 2 Place the handset on the base to charge.
- 3 After 24 hours, plug the telephone line cord into the telephone wall socket.

2 Charge

Important: Charge the handset batteries for 24 hours or your phone may not work.



General information

For information on safety instructions, cleaning, technical information or connecting to a switchboard, please refer to the 'General Information' section in the full user guide at www.bt.com/producthelp

Guarantee

Your BT Diverse 7450 is guaranteed for a period of 12 months from the date of purchase.

Subject to the terms listed below, the guarantee will provide for the repair of, or at BT's or its agent's discretion the option to replace the BT Diverse 7450, or any component thereof, (other than batteries), which is identified as faulty or below standard, or as a result of inferior workmanship or materials. Products over 28 days old from the date of purchase may be replaced with a refurbished or repaired product.

The conditions of this guarantee are:

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is required.
- The equipment is returned to BT or its agent as instructed.

This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.

This guarantee does not affect your statutory rights.

For further information within and outside the 12 month guarantee, please refer to the full user guide at www.bt.com/producthelp

Product disposal instructions

The symbol shown here and on the product means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life.

The Waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increasing landfill.

Product disposal instructions for residential users

When you have no further use for it, please remove any batteries and dispose of them and the product as per your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.

Product disposal instructions for business users

Business users should contact their suppliers and check the terms and conditions of the purchase contract and ensure that this product is not mixed with other commercial waste for disposal.

Warning

This equipment is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services.


R&TTE Directive & Declaration of Conformity

This product is intended for use within the UK for connection to the public telephone network and compatible switchboards.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive (1999/5/EC).

For a copy of the Declaration of Conformity please refer to www.bt.com/producthelp

If you ever need to remove the batteries, simply slide open the battery compartment cover and using the finger holes grip the batteries and pull them out.



1 Plug in

The telephone line cord is pre-installed but don't plug the other end into the wall socket yet.

Plug in the power adaptor with the blue end into the wall socket and switch on.

Plug the other end of the power adaptor into the wall socket and switch on.

BT Diverse 7450 User Guide



- 1 Plug in
- 2 Charge
- 3 Go!



Setting up is easy. Just follow the simple steps in this guide.

If you need further assistance, please visit our website www.bt.com/producthelp to view our advanced user guide or call our helpdesk on 0800 218 2182*

* Calls made from within the UK mainland network are free. Mobile and International call costs may vary.

Offices worldwide

The services described in this publication are subject to availability and may be modified from time to time. Services and equipment are supplied subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of a contract.

© British Telecommunications plc 2009.
 Registered Office: 81 Newgate Street, London EC1A 7AJ.
 Registered in England No. 1800000.

Designed and produced by The Art & Design Partnership Ltd.

Printed in China / Issue 1 / ADP11-09



Your phone

Handset

Indicates new text messages.
Range indicator: On=in range. Flashing=out of range or not registered to base.

- BT** Opens BT Services menu.
- Redial** Press to open and scroll through Redial list. In talk mode adjusts earpiece volume. Scroll up.
- Left soft key** Press to access names in the phonebook. Select options on screen. Go back to previous menu level and clear digits and characters.
- Make/receive a call** In talk mode, press to switch handsfree on/off.
- Scroll left** Scroll left through menu options available. Move cursor to the left.
- 1** Use to enter a space when entering text.
- * (Mute)** Press and hold to switch handset ringer on/off. When entering text, press to switch between upper and lower case letters.
- R** For use with switchboard/PBX and BT Calling Features.
- Intercom** Use to make internal calls (where more than one handset is registered).
- Indicates new missed calls. To remove the icon you need to view missed calls. See the Caller Display section below.
- Alarm set.
- Handset ringer off.
- The keypad is locked.
- Battery status indicator. (scrolls to indicate charging)
- Headset socket (on side of handset)** Headset not included. See full user guide online at www.bt.com/producthelp for further details and where to obtain a suitable headset.
- Right soft key** Press to enter menu. Press to select the option displayed on the screen.
- End a call** Press and hold to switch handset off/on. In talk mode, press to return to standby.
- Scroll right** Scroll right through menu options available. Move cursor to the right.
- Calls** Opens Calls list. In talk mode, adjusts earpiece volume. Scroll down.
- # (Lock)** Press and hold to lock/unlock the keypad.
- 0 (Pause)** Press and hold to enter a Pause in a phonebook entry. Use to enter punctuation marks when entering text.

Base

- Power/In use light** Green light flashes when phone rings, during a call and handset registration.
- Skip** Press once to repeat current message, twice to play previous message.
- Message light** On when the answer machine is on. Red icon flashes when there are new messages.
- Stop** Stop play back.
- Skip** Skip forward to next message.
- Find** Ring handsets registered to the base.
- Delete** Delete messages.
- Find** Find messages.
- Ans. on off** Switch answer machine on/off.
- Play** Play messages.
- Vol. + / Vol. -** Adjust speaker volume during play back.
- SIM card tray** Insert a SIM card to copy entries to or from the phonebook.
- BT Diverse**

3 Go!

Making calls

Press **Call** then dial the phone number. Press **End** to end the call.

Answering calls

If you have subscribed to Caller Display, the caller's details will be displayed before you answer (see the full user guide online at www.bt.com/producthelp for details).

Lift the handset from the base to answer incoming calls.

If the handset is **not** on the base, press **Call**.

Handsfree

Press **Call** during a call to switch the call to loudspeaker.

Secrecy

Press the left soft key **Secrecy** during a call to activate secrecy mode.

Press the left soft key **Secrecy** again to return to your caller.

Redial

Press **Redial**, scroll **Redial** or **Calls** to choose the number you want. Press **Call** to redial the number.

Phonebook

Storing new directory entries manually (up to 200)

Press **Names**. **New Entry** is highlighted, press **OK**.

Enter the name then press **OK**. You may need to press the same button a few times until the letter you want is displayed. For example, press **2** once for **A**, or twice for **B**.

Number is displayed. Enter the number and press **OK**.

GROUP is displayed and the group ringtone melody is played (you cannot change the ringtone at this stage). To add the entry to a call group, scroll **Left** or **Right** to select a group and press **OK**. Display shows **Saved** (if you don't want to use this feature simply select **No GROUP** for all entries).

For further information on call groups or to select call group ringtones, please refer to the full user guide online at www.bt.com/producthelp

Dialling a directory entry

Press **Names**, scroll **Redial** or **Calls** to the entry you want. Press **Call** to dial the number.

SIM card reader/writer

Copy phonebook entries to or from a SIM card

Please note the following points otherwise copying will not work: If your SIM card is PIN protected you must remove the PIN before taking the SIM out of your mobile. Entries must be stored on the SIM card itself and not just in your mobile phonebook.

Insert the SIM card into the SIM card tray on the side of the base. The SIM should have the gold chip facing upwards.

Press **Names**, **New Entry** is displayed. If no phonebook entries are present, scroll **Calls** to **SIM COPY** and press **OK**. If phonebook entries exist, scroll **Calls** to any entry and press **Options**. Scroll **Calls** to **SIM COPY** and press **OK**.

Press **Redial** or **Calls** to select either **SIM to Phone** or **Phone to SIM** and press **OK**. Select a phonebook entry using **Redial** or **Calls** and press **OK**.

Press **Redial** or **Calls** to highlight **COPY Entry** or **COPY ALL** and press **OK**.

If you choose **COPY Entry**, each individual entry will need to be copied in this way. When each entry or all entries are transferred successfully, the display will show **Copied**.

Caller Display and the Calls list

You must subscribe to a Caller Display service for this feature to work. Your network provider may charge you for this service.

View and dial from the Calls list

Press **Calls**, the most recent entry in the list is displayed. Press **Redial** or **Calls** to scroll through the list.

Press **Options**. **Details** is highlighted, press **OK**. The call details will be displayed.

Press **Call** to dial a displayed entry.

Answering machine

Your answering machine is on and ready to record messages. The controls are shown in the base diagram to the bottom left and the features can also be accessed via the handset Answer Machine menu.

Recording your own outgoing message

Press **Menu**, scroll **Right** to **Answer Machine**, press **OK**.

Press **Calls** to scroll to **Outgoing Message** and press **OK**. Scroll **Calls** to **Record Message** and press **OK**.

Press **Redial** or **Calls** to select **Answer & Record** or **Answer Only** and press **OK**.

After the long beep, speak your message into the handset. When finished, press **Save**. Your message will be played back to you. If you want to delete it, press **Delete** during playback, or press **OK** to save it.

Ring delay (set number of rings before answer machine picks up the call)

For compatibility with the BT 1571 service do not set the ring delay to more than 6 rings.

Press **Menu**. Scroll **Right** to **Answer Machine**. Press **OK**.

Scroll **Calls** to **Answer Settings** and press **OK**.

Scroll **Calls** to **Answer Delay** and press **OK**. Press **Redial** or **Calls** to select the number of rings (2-9 or Time Saver) and press **OK** to save.

For detailed instructions on all the answering machine features see the full user guide online at www.bt.com/producthelp


Text messaging

Before sending and receiving text messages you need to register to the text messaging service and subscribe to Caller Display. You will be automatically registered to the text message service when you send your first text. See the full user guide online at www.bt.com/producthelp for details.

Help

Most problems can be fixed with a few simple checks.

Problem	Solution
No dial tone	Only use the cables and batteries supplied. Make sure both the power adaptor cable and telephone line cord are plugged into the correct sockets on the base. Make sure the power is switched on at the power wall socket and that the telephone line cord is plugged in correctly at the telephone wall socket.
Poor speech quality	Make sure the product is not located too close to other electrical appliances. This can also help improve the handset range from the base.
Battery icon not full/handset dead	Make sure you charge the batteries for 24 hours before use to ensure maximum battery performance.
Using broadband on the same phone line?	Make sure you plug the phone into the wall socket via an ADSL microfilter (not supplied), otherwise you may have problems with this product and your broadband service.



Find out more

- New Frequently Asked Questions available at www.bt.com/producthelp
- If you need more detailed instructions, a full user guide is available to download from www.bt.com/producthelp
- If you cannot find the answer to your problem in the full online user guide, then please call the free Helpline on 0800 218 2182* or email bt.helpdesk@vtecheurope.com. Our dedicated advisors are more likely to be able to help you than the retailer where you made your purchase.
- This document is also available in other formats, such as Large print, Braille and Audio CD. If you would like a copy, please call 0800 218 2182*